



	DESIGN	DRAWN BY	DART AEROSPACE US	
	CHECKED	APPROVED	DRAWING NO.	REV. A
	KE	14	DEO 9098	SHEET 1 OF 1
	DATE	. ,	TITLE	SCALE
	98.01.14		206B GHW MODIFICATION	1:3
Ī	Δ	98 01 14	NEW ISSUE	



DART ENGINEERING ORDER

TO AMEND DRAWING D2650 REV. C FOR D2650-1 AND D2650-3 ONLY

DO NOT WELD D2649 SPACERS IN THE 2 SETS OF HOLES DIRECTLY IN FRONT OF THE AFT SADDLE HOLES. THESE HOLES SHOULD BE FINISHED AS FOLLOWS:

- 1) DRILL HOLES TO Ø0.500 (4 PLACES)
- 2) REMOVE OUTER RIDGE AS INDICATED TO LEAVE MAX SKIDTUBE DIAMETER OF 3.150
- 3) LOCATE D2737-041 STUDS (4 REQ'D) IN PLACE, SEALING COMPLETELY UNDERNEATH WITH SIKAFLEX 241
- 4) TRANSFER DRILL Ø0.125 TO SKIDTUBE
- 5) INSTALL CR3213-4-3 RIVETS (16 REQ'D)

NOTE: STEPS 3), 4), AND 5) SHOULD BE COMPLETED AFTER POWDER COAT.

